

BATTERIES FOR YOUR SMART DIGITAL LOCKS

FAQ: Batteries for igloohome door lock



Here's a question we receive on a daily basis: What kind of batteries should I be using for my igloohome door lock?

Quick battery tips:

1. Always use alkaline batteries.
2. Energizer, Duracell & Panasonic work best.
3. Change batteries every 8 - 10 months.
4. Diligently check for battery leakage every 6 months.
5. Avoid lithium, carbon-zinc and rechargeable batteries altogether.

*Smart Padlock is the only exception that uses lithium batteries.

All igloohome door locks come with a pack of batteries, however, these are used for testing purposes after the installation is complete. We always recommend for you to change them out once the testing is done.

For optimum results, we only recommend alkaline batteries. These types of batteries work best with our locks and can typically last up to 12 months depending on the frequency of your usage.

The brands to get are Energizer, Duracell and Panasonic. As a rule of thumb, batteries should be changed every 8 - 10 months to prevent battery liquid leaks. We do not advise for you to leave batteries in the lock for more than a year as the battery cell expands towards the end of its lifecycle due to chemical changes. This could lead to higher risks of battery liquid leaks in that period.

Avoid lithium and carbon-zinc batteries as these run out of power much faster than alkaline ones. Neither should you use rechargeable batteries as the power is lessened with each recharge.

Should you encounter any issues with your lock, feel free to reach out to us at sales@tamsons.com.ph. We're always happy to help!